

Aluminium Poster Browser - A1 A3



Aluminium Poster Browser - A1 & A3



A1

Supplied with = 5x A1 Poster Frames

5x Swivelling Insert Frames

2x Wall Brackets

Insertion is on the long-side of frame

Document insertion max width = 4.5mm

*Designed to add = **10x A1 Documents***

A3

Supplied with = 5x A3 Poster Frames

5x Swivelling Insert Frames

2x Wall Brackets

Insertion is on the long-side of frame

Document insertion max width = 4.5mm

*Designed to add = **10x A3 Documents***

Step 1 - Poster Frames

- 1 *Aluminium Poster Frames, create a very long-lasting display system*
 - 2 *They have a capability of document / board insertion up to 4.5mm*
 - 3 *They have in-built top & bottom rods, for inserting into the wall bracket(s)*
- Frames are supplied empty (no clear internal sleeves)*

Step 2 - Wall Bracket

- 1 *Wall bracket maybe supplied as a 1x Large Bracket - or - 2x Smaller Brackets*
- 1 *Wall bracket has pre-drilled holes for attaching to the wall*
- 2 *Wall bracket(s) have 5x pre-drilled holes for inserting the frames into*

Step 3 - Safety First

- 1 *Before starting - check for any internal Electric cables & Water pipes*

Step 4 - Fitting

- 1 *Gather 1x small spirit level & 1x pencil*
- 2 *Hold the wall bracket to the wall, check its 100% level (spirit level)*
- 3 *Once 100% level, mark the retaining hole areas, with the pencil*
- 4 *Remove bracket from the wall*
- 5 *Gather 1x drill & drill the holes to the depth of the supplied raw plugs*
- 6 *Now insert the raw plugs*
- 7 *Now using the screws supplied, secure the wall bracket to the wall*
- 8 *Now fill each frame with 2x documents / cards / boards etc*
- 9 *Now simply insert each frame into the wall bracket...*
- 10 *This is done by a simple lift up and dropping action*