

Fitting Instructions

Image:

Burgundy A3 Landscape LED

Ex-Showroom Usage (Reduced Costs)



Window

Standard Fitting - Decide if you want the power cable to be seen

Pro Fitting - Decide if you want the power cable to be hidden

Standard Fitting -

Secure holding bracket to your window sill

Secure the LED on top of the Chrome Pole

Thread LED cable through the Chrome Pole

Secure Chrome Pole to the Holding Bracket

Plug in the transformer - that's it

Pro Fitting -

Decided on wanted mounted location

Now drill a hole through the holding bracket into the window sill

Secure holding bracket to your window sill

Secure the LED on top of the Chrome Pole

Thread LED cable through the Chrome Pole & into the window sill

Secure Chrome Pole to the Holding Bracket

Plug in the transformer - that's it

Power

Each LED unit demands 10W of power

If requested we can supply say 4x LED units & 1x 60W Transformer

This way, you turn on 1x 60W Transformer to power up 4x LEDs

Thus avoiding un-sightly excess electric cable

Surge

We would also recommend that you utilise a Surge Protector

Why? - Avoids any unwanted excessive power surge - plus - costs very little

Back-Lit Paper - or - Back-lit Film

For best results always print on Back-Lit Paper - or Film, as this allow your property details, to gain the full effect in Illumination

For more details - Tel: **01244 470903**