

Fitting Instructions

Image:

Silver 3x A3 Landscape LED

Ex-Showroom Usage (Reduced Costs)



Design:

- 1 Designed to be mounted on a window sill
- 2 Designed to advertise 3x A3 Landscape Property Documents
- 2 Designed also, for 6x A4 Portrait Property Documents

Step 1 - Window Sill

- 1 Connect the Post Bracket to your window sill
- 2 **Standard Fitting** - Cable is revealed at the bottom
Pro Fitting - Drill a hole to feed your cable underneath the sill
Pro fitting - (This is only possible, If you have under sill access)
- 3 Connect the Post to the bracket, securing with the Grub Screws

Step 2 - Cable

- 1 **1st LED** - (Top) - Connect this to the post
Decide on the wanted gap before the 2nd LED
- 2 **2nd LED** - (Central) - Connect this to the post
- 3 **3rd LED** - (Bottom) - Connect this to the post

Step 3 - Power

- 1 Feed each connection cable down the inside of the post
- 2 Connect these 3x cables, to the transformer cable
- 3 We would advise that you plug a 'Surge Protector' to your wall socket
Then, plug the 'Transformer' into the 'Surge Protector'
Once all connected - Turn on the Power

Step 4 - Documents

- 1 Print your 3x A3L Documents or 6x A4P Documents
- 2 Then, slightly de-magnetise the LED frame to insert them within each LED

Back-Lit Paper - or - Back-lit Film

For best results always print on Back-Lit Paper - or Film, as this allow your property details, to gain the full effect in Illumination

For more details - Tel: **01244 470903**